



# T-CVTAC



**This tool allows the movement of variators to allow the removal of drive belts. This tool has many slots and holes to fit future needs. At this time there are 2 clamp sizes (A&B) that fit 3 different variators including Nissan, Ford and Saturn. More clamp sizes will be available as an add on to the puller. Clamp C will be for Subaru.**

**NOTE: Install 2 cord ties on drive belt to help keep it together.**

- 1.) Select the right size clamp use bolts supplied to assemble with upright in between clamp making sure its level then tighten until snug.**
- 2.) Insert threaded handle through cross bar then install (PUSH) tapered foot on the snap ring. Use pins to connect uprights to cross bar to complete puller assembly.**
- 3.) Make sure tapered foot is sitting square in shaft. Tighten by hand until drive belt is free.**



**WORK SMARTER NOT HARDER**

[www.ADAPT-A-CASE.com](http://www.ADAPT-A-CASE.com)

